

WINDSCREEN RUBBERS

BEDFORD

OZ 1124 CF Bedford 1970-81

No Moulds

GM276, BE951, 818840

OZ 1126 TK Bedford 1962-81

Needs GL1

GM274, BE716, 818150

CHEVROLET

OZ 1193 C20 RUBBER

No Moulds

US850

DAIHATSU

OZ 1087 Delta V10/20/30 1977-84

No Moulds

TT553, TT630, 819790

OZ 1053 Delta Wide Cab 84-03

No Moulds

DU569, TT1461, 819793

DATSUN

OZ 1097 1200 Sedan REAR

No Moulds

REAR

OZ 1011 1200 Ute 71-85

No Moulds

DN098, DN802, 230850

OZ 1101 120Y Sedan REAR

Takes Moulds

REAR

OZ 1135 1600 P510 Sedan REAR

Takes Moulds

REAR

OZ 1133 1600 P510 Sedan Wgn

1967-79

Takes Moulds

DN103, DN803, 230770

OZ 1072 720 UTE 79-85 REAR

No Moulds

REAR

DODGE

OZ 1041 AT D5N, International

No Moulds

IH534, IH796, 818600

FORD

OZ 1108 Cargo 1981-1992

No Moulds

FD168, FD1111, 838801

OZ 1010 Cortina TC-TD 71-76

Takes Moulds

FD060, FD744, 231500

OZ 1095 Escort Mk1 Sedan REAR

Takes Moulds

REAR

OZ 1008 Escort Mk2 Sedan/Coupe 75-83

Takes Moulds

FD063, FD924, 231560

OZ 1007 F100 early 57-60

Takes Moulds

FD030, FD496, 818780

OZ 1006 F100-F250 73-97 REAR

No Moulds

REAR

OZ 1005 F100-F250-F350. 68 -81

No Moulds

FD687, FD748, 838790

OZ 1132 Falcon XD-XF 1979-87

Sedan REAR

No Moulds

REAR

OZ 1136 Falcon XW XY GT F/Mont

ZC ZD F/Lane 69-72 REAR

No Moulds

REAR

OZ 1009 Ford Courier/Mazda B2000

77-85

Takes Moulds

MA071, MA784, 839330

OZ 1092 Ford Escort MK1/ MK2

Panelvan 69-82

Takes Moulds

FD062, FD664, 231550

OZ 1004 Ford Mustang 64-68

No Moulds

FD654, FD2295, 036540

OZ 1065 Louisville 75-97

No Moulds

FD828, FD926, 838320

OZ 1057 Trader Wide Cab 81-89

No Moulds

MA072, MA1254, 839311

OZ 1058 Trader Wide Cab 89-2000

No Moulds

MA073, MA1691, 819313

OZ 1151 XA XB SDN ZF ZG Fairlane

REAR

Takes Moulds

REAR

OZ 1155 XA XB XC Coupe REAR

Takes Moulds

REAR

OZ 1160 XA XB XC Ute REAR

Takes Moulds

REAR

OZ 1179 XC SED ZH F/Lane REAR

Takes Moulds

REAR

OZ 1167 XK XL XM XP 2 Dr Coupe

1960-66

Takes Moulds

FD065, FD1592, 231660

OZ 1176 XK XL XM XP Sdn Wgn

1960-66

Takes Moulds

FD064, FD1191, 231650

OZ 1165 XR XT ZA ZB REAR

No Moulds

REAR

OZ 1168 XW XY 500 Futura REAR

Takes Moulds

REAR

OZ 1178 XW XY XR XT Ute REAR

No Moulds

REAR

FORD

OZ 1113 D SERIES 1965-81

No Moulds

FD311, FD740, 818800

HINO

OZ 1163 Dutro 200, 300 Standard

Cab 2000-

No Moulds

TT105, TT1462, 838992

OZ 1175 Dutro 300, 400, 500 Wide

Cab 2000-

No Moulds

TT101, TT1463, 818993

OZ 1088 FD-FF 1982-96

No Moulds

TT171, TT1135, 818981

OZ 1188 FLEETER, MERLIN FB

1985-96

No Moulds

TT1790

OZ 1148 KL KB KR LA LB342 70-85

No Moulds

TT355, TT1914, 818980

OZ 1186 RANGER 4,5 FB FC

NARROW 1996-2002

No Moulds

TT136

OZ 1185 RANGER 6,7,8 1991-

No Moulds

TT1949

OZ 1184 RANGER PRO 5,6,7,8

STAND CAB 2003-

No Moulds

818998, TT1137

OZ 1191 RANGER PRO 8,9,10,14

1991-2002

No Moulds

TT2130

OZ 1183 RANGER PRO 9,10 WIDE

2003-

No Moulds

818997, T1991

HOLDEN

OZ 1104 Commodore VN-VS Front

87-97

No Moulds

GM714, GM1588, 232023

OZ 1142 EH Sedan 63-64 REAR

Takes Moulds

REAR

OZ 1174 EJ Sedan REAR

Takes Moulds

REAR

OZ 1066 EJ, EH, 62-64

Takes Moulds

GM075, GM1196, 231970

OZ 1217 FB EK W/S Seal

Takes Moulds

211960, GM2017

OZ 1220 FB EK Sedan REAR

Takes Moulds

REAR

OZ 1232 FE FC Standard

Takes Moulds

231950, GM2016

OZ 1199 FE FC Special

Takes Moulds

231950, GM2016

OZ 1198 FJ/FX Front & UTE Rear

No Moulds

201940, GM575

WINDSCREEN RUBBERS

OZ 1003 Gemini TX, TC, TG, 75-84

Takes Moulds
GM084, GM727, 232320

OZ 1128 HD HR 1965-67

No Moulds
GM076, GM730, 231980

OZ 1130 HD HR 1965-67

Takes Moulds
GM076, GM730, 231980

OZ 1172 HD HR HK HT HG Ute REAR

No Moulds
REAR

OZ 1181 HD SEDAN 65-66 REAR

Takes Moulds
REAR

OZ 1147 HK HT HG 2DR Monaro

68-71 FRONT
Takes Moulds
GM080, GM734, 232150

OZ 1170 HK HT HG Monaro REAR

Takes Moulds
REAR

OZ 1144 HK HT HG Premier/

Brougham 68-71 REAR
Takes Moulds
REAR

OZ 1180 HK Kingswood REAR

Takes Moulds
REAR

OZ 1106 HQ - WB Ute REAR Seal

Includes locking strip
REAR

OZ 1182 HR SEDAN 66-68 REAR

Takes Moulds
REAR

OZ 1125 HT HG HK Kingswood Sqr

Cnrs 1968-70
Takes Moulds
GM077, GM731, 231990

OZ 1122 HT HG HK Prem Sqr Cnrs

1968-70
Takes Moulds
GM077, GM731, 231990

OZ 1140 HT HG Kingswood 69-71

REAR
Takes Moulds
REAR

OZ 1127 HT HG Kingswood Sedan

Round Cnrs 68-71
No Moulds
GM078, GM732, 232000

OZ 1035 Jackaroo 81-92

No Moulds
GM154, GM1116, 232120

OZ 1002 Rodeo KB Model 81-88

No Moulds
GM047, GM1107, 232120

OZ 1118 TF Rodeo 88-03 Ute REAR

No Moulds
REAR

OZ 1138 Torana LC LJ 2/4 Dr 67-74

FRONT
Takes Moulds
GM082, GM736, 232250

OZ 1141 Torana LC LJ 2/4 Dr 67-74

REAR
Takes Moulds
REAR

OZ 1137 Torana LH LX UC Sedan

REAR
Takes Moulds
REAR

OZ 1052 Torana LH, LX, U 4 door

sedan/5 door hatch 74
Takes Moulds
GM083, GM737, 232260

OZ 1152 Torana LX UC Hatchback

REAR
Takes Moulds
REAR

OZ 1162 VB-VH Commodore REAR

Mylar Only
REAR

OZ 1158 VB-VH Exc

Mylar Only
GM464, GM763, 232020

OZ 1091 VB-VK Front Windscreen

Rubber
No Moulds
GM464, GM963, 232020

OZ 1156 VC-VK SL/E Calais

Solid Chrome Only
GM464, GM763, 232020

OZ 1166 VC-VL SL/E Calais REAR

Takes Moulds
REAR

OZ 1105 VK-VL Sedan REAR

No Moulds
REAR

INTERNATIONAL

OZ 1036 3 WiperAcco 73-

Includes locking strip
IH320, IH798, 819030

OZ 1041 AA110, C1100, D1910

No Moulds
IH534, IH796, 818600

OZ 1063 CMA,B 86, 87, N-1630

83-96
No Moulds
IH460, IH1428, 818491

OZ 1056 T-Line 79-

Includes locking strip
IH713, IH1008, 839060

JAGUAR

OZ 1231 XJ6 Ser1/2 1969-1979

REAR
Takes Moulds
230710 REAR

ISUZU

OZ 1189 FRR, FSR, FVM, FVR, FTR,

FVZ 1996-08
No Moulds
GM2003

OZ 1120 FSR, FSS, FTR, FVM, FVR,

FVZ 1986-96
No Moulds
GM650, GM1519, 818221

OZ 1112 SBR JBR JCR JCM

1975-86
No Moulds
GM322, GM876, 818220

IVECO

OZ 1045 Stralis, Powerstar,

Eurotech Rubber 95-
No Moulds
IH202, IH2075, 819075

JAGUAR

OZ 1119 XJ6 Series I+II 1969-79

Takes Moulds
JG205, JG710, 230710

KENWORTH

OZ 1145 K100G Flat 1/2 Screen

Includes locking strip
KW006, KW1014, 819114

OZ 1146 K104 K108 K200 1999-

Includes locking strip
KW714, KW1015, 819125

OZ 1116 K104 K108 K200 Half

Screen 1999-
Includes locker
KW715, KW1016, 1017, 819123, 819124

OZ 1131 T601, T605, T900, T950

High Roof 1995-
Includes locking strip
KW003, KW764, 839112

LAND ROVER

OZ 1046 Defender 84- Front screen

rubber
No Moulds
RV599, RV1469, 819141

OZ 1051 Range Rover 2 door/4

door 70-93
Needs GL1
RV250, RV711, 214120

LEYLAND/MORRIS

OZ 1047 Mini 850 W/S Rubber &

locker
Includes locking strip
LY001, LY701, 233600

MAZDA

OZ 1068 Parkway Bus 72-81 H

Rubber 6 Metre +
Includes locker
MA493, MA1036, 819360

OZ 1057 T3000 Wide Cab 81-89

No Moulds
MA072, MA1254, 839311

OZ 1058 T3000 Wide Cab 89-2000

No Moulds
MA073, MA1691, 819313

MERCEDES BENZ

OZ 1099 114/115 SEDAN

Takes Moulds
MB224, MB884

OZ 1100 114/115 SEDAN REAR

Takes Moulds
REAR

OZ 1093 116 SDN 1973-80 REAR

Takes Moulds
REAR

WINDSCREEN RUBBERS

OZ 1055 123 Chassis Sedan/Wagon

76-85

Takes Moulds

MB123, MB903, 233420

OZ 1048 Actros W/S Rubber OE

No Moulds

MB338, MB2150, 819381

OZ 1054 Coach S80-S85 1986-

Takes Moulds

MB086/087, MB8003/8004,
839451/839461

OZ 1194 G SER W460-463 FRONT

RUBBER

No Moulds

MB1416 / MB1415 / MB1416

OZ 1074 LS 1418 HIGH CAB FRONT

No Moulds

MB524, MB891, 819400

OZ 1107 V SERIES STANDARD CAB

1974-1997

No Moulds

MB337, MB902, 819430

MITSUBISHI

OZ 1067 Canter FE200 Wide Cab

1978 - 1985

No Moulds

CH767, CH1056, 818650

OZ 1109 Canter FE300 FE339

Narrow Cab 1986-95

No Moulds

CH628, CH1655, 818653

OZ 1049 Canter Front Wide Cab, 86-96 FE444

No Moulds

CH627, CH1530, 818652

OZ 1061 FK 415, FM 555 85-95

No Moulds

CH589, CH1368, 838632

OZ 1114 FUSO FK102 FM215

1982-92

No Moulds

CH724, CH1055, 818631

OZ 1039 L200 Ute 79-86

No Moulds

CH673, CH999, 838660

OZ 1018 L300 81-86

No Moulds

CH730, CH1046, 838670

OZ 1089 L300 FRONT 1986-

No Moulds

, CH655, CH1527, 818671

OZ 1016 Pajero NC-NF-NG-No

Mould 83-91

No Moulds

CH340, CH1326, 235180

OZ 1069 Rosa Bus 1986 - 2000

No Moulds

CH023, CH1977, 838673

OZ 1070 Rosa Bus 2000 -

No Moulds

ECH073, CH1979, 838679

MORRIS

OZ 1207 MINI 1962 - 80 REAR

Needs GL1

REAR

NISSAN

OZ 1015 720 Datsun Ute 79 - 88

Takes Moulds

DN633, DN1010, 838400

OZ 1072 720 Ute REAR

No Moulds

REAR

OZ 1075 ATLAS CABSTAR F23

No Moulds

DN051, DN2346, 818483

OZ 1134 ATLAS CABSTAR F23 H41

No Moulds

DN415, DN2137, 818464

OZ 1110 Cabstar H40 F22 STD CAB 82-95

No Moulds

DN205, DN1410, 818481

OZ 1032 Civilian Bus 82 - 99

No Moulds

DN562, DN1353, 838399,

OZ 1071 NAVARA D21/D22 REAR

No Moulds

REAR

OZ 1153 Patrol G60, 61 4WD Wagon

1960-81

No Moulds

DN118, DN1436, 818420

OZ 1195 PATROL GQ

Takes Moulds

DN1069

OZ 1040RBL Patrol GU REAR barn door L/H (small)

REAR

OZ 1040RBR Patrol GU REAR barn door R/H (large)

REAR

OZ 1014 Patrol MQ GQ 80-97

No Moulds

DN771, DN1069, 838421

OZ 1014RCR Patrol MQ GQ y60 4x4 wgn. Fixed cargo window rubber right hand side 80-97

SIDE

OZ 1014RBL Patrol MQ patrol REAR barn door L/H

No Moulds

REAR

OZ 1014RBR Patrol MQ patrol REAR barn door R/H Large

No Moulds

REAR

OZ 1013 Urvan E23 80-86

Takes Moulds

DN987, DN1094, 838391

OZ 1012 Urvan E24 87-93

No Moulds

DN679, DN1552, 818392

OZ 1111 CABSTAR H40 Truck Wide CAB 82-95

Takes Moulds

DN206, DN1411, 818482

NISSAN / UD

OZ 1129 CWB320, CWB350, CWB450, CW320, CW350, CW380 1991-

No Moulds

DN626, DN2163, 818413

OZ 1121 PK220, PK235, PK240, PK245, PK250, PK265, CW250, MK250 Wide Cab 95-

No Moulds

DN076, DN2136, 818462

OZ 1115 UD MK, LK Narrow Cab

1995-

No Moulds

DN072, DN1960, 818463

PORSCHE

OZ 1227 911 65/89 Front

Takes Moulds

233830, PS946

SCANIA

OZ 1150 P, R 2 & 3 Series 1981-97

No Moulds

SV270, SV1365, 819531

OZ 1044 P,R "4 series" Screen Rubber 1997 - 2004

No Moulds

SV271, SV1407, 819532

SUBARU

OZ 1019 Brumby 80-93

Takes Moulds

SU711, SV992, 234320

SUZUKI

OZ 1080 SIERRA 1981 -91

No Moulds

SZ114, SZ1129, 234351

TOYOTA

OZ 1084 Celica TA20-22 1971-77

No Moulds

TT152, TT826, 234840

OZ 1098 Celica TA22 COUPE REAR

No Moulds

REAR

OZ 1050 Coaster BB20 1981 - 1993

No Moulds

TT404, TT965, 839721

OZ 1060 Coaster BB50 HBZ50 93-

No Moulds

TT025, TT2300, 819722

OZ 1082 Corolla Ke20 2/4 DR REAR

Takes Moulds

REAR

OZ 1081 Corolla Ke20 70-74

Takes Moulds

TT147, TT822, 234710

OZ 1031 Corolla Ke30 74-83

Takes Moulds

TT148, TT923, 234730

OZ 1079 Corolla Ke30 REAR

Takes Moulds

REAR

OZ 1094 Corolla KE70 REAR

Takes Moulds

REAR

WINDSCREEN RUBBERS

OZ 1083 Crown MS50 1967-71

No Moulds

TT160, TT828, 234400

OZ 1096 CROWN MS50 REAR

No Moulds

REAR

OZ 1087 Dyna BU20 1977-84

No Moulds

TT553, TT630, 819790

OZ 1192 Dyna/Delta Narrow Cab

84-03

No Moulds

81972, TT1460

OZ 1053 Dyna Wide Cab 84-03

No Moulds

DU569, TT1461, 819793

OZ 1187 FJ45 LANDCRUISER UTE

REAR

No Moulds

REAR

OZ 1190 FJ45 LANDCRUISER UTE

REAR 1/4

No Moulds

REAR

OZ 1038 Hi Ace 89-05

No Moulds

TT791, TT1680, 839782

OZ 1086 Hi-Ace 1989- 2005

TAILGATE REAR

No Moulds

REAR

OZ 1030 Hi-Ace RH20/30 77-83

No Moulds

TT420, TT607, 839780

OZ 1029 Hi-Ace YH50-53 84-89

No Moulds

TT330, , TT1151, 839781

OZ 1078 Hi-Lux 83-97 REAR

No Moulds

REAR

OZ 1117 Hi-Lux 88-97 REAR

No Moulds

REAR

OZ 1020 Hi-Lux Ln106 88-97

No Moulds

TT727, TT1600, 839674

OZ 1076 Hi-Lux RN20 72-78

No Moulds

TT350, TT837, 819670

OZ 1077 Hi-Lux RN30/40 1978- 83

REAR

No Moulds

REAR

OZ 1028 Hi-Lux RN30-40 78-83

No Moulds

TT584, TT991, 839671

OZ 1027 Hi-Lux RN50-60 84-88

No Moulds

TT561, TT1360, 839672

OZ 1023 Landcruiser 60 Series

80-90

No Moulds

TT996, TT1096, 839691

OZ 1022 Landcruiser 60 Series

80-90

Takes Moulds

TT996, TT1096, 839691

OZ 1021 Landcruiser 75 Series

Ute 84-99

No Moulds

TT573, TT1507, 839692

OZ 1037 Landcruiser 80 Series

90-97

No Moulds

TT790, TT1799, 839694

OZ 1033 Landcruiser 80 Series

90-97

Takes Moulds

TT790, TT1799, 839694

OZ 1026 Landcruiser FJ45 76-80

Late Model Wiper Bottom

No Moulds

TT166, TT853, 839750

OZ 1025 Landcruiser FJ45 Early

Model 65-75 Wiper Motor at top

Includes locking strip

TT165, TT834, 819730

OZ 1024 Landcruiser FJ55 67-80

No Moulds

TT167, TT832, 839690

OZ 1034 Landcruiser Troopy

85-95, UTE 99-

No Moulds

TT572, TT1492, 839693

OZ 1085 Liteace KM20 1979-85

No Moulds

TT728, TT1012, 839655

TRIUMPH

OZ 1196 STAG 72-78

Takes Moulds

TR708

UD

OZ 1064 CGA, CKA 45, 46 83-92

No Moulds

DN981, DN2202, 818411

OZ 1073 CK20/CW40 1971-91

No Moulds

DN293, DN2070, 818410

OZ 1063 CMA,B 86, 87, N-1630

83-96

No Moulds

IH460, IH1428, 818491

OZ 1062 CPC 14, 15 85-95

No Moulds

DN, 625, DN1547, 818412

OZ 1134 MK120 MK150 1999-

No Moulds

DN415, DN2137, 818464

UD / NISSAN

OZ 1129 CWB320, CWB350,

CWB450, CW320, CW350, CW380

1991-

No Moulds

DN626, DN2163, 818413

OZ 1121 PK220, PK235, PK240,

PK245, PK250, PK265, CW250,

MK250 Wide Cab 95-

No Moulds

DN076, DN2136, 818462

OZ 1115 UD MK, LK Narrow Cab

1995-

No Moulds

DN072, DN1960, 818463

VALIANT

OZ 1157 AP5 AP6 VC Ute REAR

Takes Moulds. MADE TO ORDER

REAR

OZ 1169 AP5 AP6 VC Valiant Sdn

63-67 REAR

Takes Moulds

REAR

OZ 1139 AP5 AP6 VC Valiant Sdn

Wgn Ute 63-67 FRONT

Takes Moulds

CH029, CH755, 235250

OZ 1216 R & S Series

Takes Moulds

235240, CH750

OZ 1164 VE VF VG Sdn REAR

Takes Moulds

REAR

OZ 1143 VE VF VG Sdn Wgn Ute

67-71 Front

Takes Moulds

CH030, CH757, 253260

OZ 1154 VF VG Coupe 1969-71

Takes Moulds

CH031, CH752, 235270

OZ 1149 VF VG Coupe REAR

No Moulds

REAR

OZ 1161 VF VG VIP Sedan 1967-71

REAR

Takes Moulds

REAR

OZ 1159 VH-CM Charge REAR

Takes Moulds

REAR

OZ 1173 VH-CM Coupe REAR

MADE TO ORDER

REAR

OZ 1171 VH-CM Sedan REAR

Takes Moulds. MADE TO ORDER

REAR

OZ 1177 VH-CM Ute REAR

Takes Moulds. MADE TO ORDER

REAR

OZ 1123 VH-VK CM, CL Charger

1971-81

Mylar Only

CH032, CH760, 235040

VOLKSWAGEN

OZ 1102 Beetle 1.3 FRONT

Takes Moulds

VW170, VW761, 215500

OZ 1103 BEETLE 1.3 REAR

Takes Moulds

REAR

OZ 1042 Kombi van 68-81

No Moulds

VW176, VW763, 235660

VOLVO

OZ 1043 FH 12-16 FM7 FM12

Globetrotter

No Moulds

W015, VV2374, 819913