

## Rain Sensors

BLANK

### OZ ST01 Heater Box for Sensor Gel



Designed to improve curing times in cold temperatures. Speeds up curing time from 15 to 20 minutes when using OZ ST02 refill.

### OZ ST02 Sensor Gel Refill Pack (Clear)



One application

### OZ ST03 Sensor Gel Refill Pack (Opaque)



For most VWs 2006 and some other European models

### OZ ST04 Mould for OZ ST03 Gel Refill Pack



For Use With OZ ST03 Gel

### OZ 801RS Mercedes & Chrysler Adhesive Rain Sensor Pads - Pkt 5



70mm x 43mm

### OZ 802RS VW & Chrysler Adhesive Rain Sensor Pads - Pkt 5



26mm diameter

### OZ 805RS Alfa, Mercedes & BMW Adhesive Rain Sensor Pads - Pkt 5



55mm x 33mm

### OZ 817RS E46 BMW, Mercedes Adhesive Rain Sensor Pads - Pkt 5



60mm x 35mm

POPULAR

### OZ AUDIRS Audi Rain Sensor Pad



#### Suits: AUDI

- ★ A1 (10-)
- ★ A3 + Sportback (04-)
- ★ A3 Cabrio (08-)
- ★ A4 Facelift (04-07)
- ★ A4 (07-)
- ★ A4 Cabrio
- ★ A4 Cabrio Facelift (06-)
- ★ A5 (07-)
- ★ A5 Cabrio (09-)
- ★ A6 (04-)
- ★ A6 (11-)
- ★ A7 (10-)
- ★ A8 (07/03-)
- ★ A8 (10-)
- ★ TT (06-)
- ★ TT Cabrio (07-)
- ★ R8 (07- ★ Q5 (08- ) ★ Q7 (06- )

#### Suits: FORD

- ★ Focus (11-)
- ★ Kuga (12-)
- ★ Ranger (11-)

#### Suits: SEAT

- ★ Altea/Toledo (04-)
- ★ Leon II (05-)
- ★ Exeo (09-)

#### Suits: ALDO

- ★ PORCHE Cayenne (10-)
- ★ TOYOTA Avensis (09-)
- ★ VW Touareg (10-)

### OZ ST05 Subaru/Suzuki Sensor Pad - 34 x 26mm



#### Suits:

- ★ SUBARU Liberty/Outback (09-)
- ★ SUZUKI Kizashi (10-)

### OZ ST06 Toyota/Lexus Sensor Pad - 25 x 34mm



#### Suits: LEXUS

- ★ CT (11-)
- ★ RX (10-)
- ★ Sienna (10-)

#### Suits: MAZDA

- ★ MAZDA 2 (11-)
- ★ MAZDA 3 (10-)
- ★ MAZDA CX5

#### Suits: TOYOTA

- ★ Camry (06-)
- ★ Landcruiser (10-)
- ★ Prius (09-)
- ★ RAV 4 (05-)

### OZ ST07 H1 Sensor Pad - Ø44mm



#### Suits: MERCEDES

- ★ Actros (08-)
- ★ A Class W169 (04-)
- ★ B Class W245 (05-)
- ★ SLK R171 (04-)
- ★ Sprinter II (06-)
- ★ Vito II (03-)
- ★ Colt VI 3 doors (05-)
- ★ Colt VI 5 doors (04-)

#### Suits: NISSAN

- ★ 370 Z Cabrio (10-)
- ★ Cube (09-)
- ★ Juke (2011-)
- ★ Micra (11-)
- ★ Micra K12 (03-)
- ★ Micra K13 (11-)
- ★ Murano (08-)
- ★ Note (06-)
- ★ Pathfinder II (06-)
- ★ Patrol Y62 (13-)
- ★ Dualis (07-)
- ★ Tiida (04-)
- ★ X Trail (07-)

#### Suits: RENAULT

- ★ Clio III (05-)
- ★ Koleos (08-)
- ★ Mégane II (02-)

#### Suits: ALDO

- FIAT ★ Ducato III
- PEUGEOT ★ Boxer (06-)
- SMART ★ Roadster (03-)

### OZ ST08 H2 Sensor Pad - Ø44mm



#### Suits: BMW

- ★ 5 Series F10/F11 (10-)
- ★ 5 Series GT F07
- ★ 6 Series F12/F13 (11-)
- ★ 7 Series F01/F02 (08-)
- ★ X3 F25 (10-)
- ★ X5 E70 (07-)
- ★ X6 E71 (08-)

#### Suits: NISSAN

- ★ Qashqai (14-)
- ★ X-Trail (14-)

#### Suits: RENAULT

- ★ Kangoo III (08-)
- ★ Koleos (15-)
- ★ Laguna III (07-)
- ★ Laguna III Coupé (08-)
- ★ Mégane III 5 doors (08-)
- ★ Mégane III CC (10-)
- ★ Mégane III Coupé (08-)
- ★ Mégane Scénic III (09-)
- ★ Wind (10 VW Beetle (11-)

#### Suits:

- SMART ForTwo (07-)

## Rain Sensors...

### OZ ST09 Type 7 Sensor Pad - 37 x 50mm



**Suits: JAGUAR**

★ XJ (10-) ★ XK (06-)

**Suits: LAND ROVER**

★ Discovery III (04-)  
★ Evoque (11-)  
★ Freelander II (07-)  
★ Range Rover Sport (05-)

**Suits: SKODA**

★ Fabia II (07-) ★ Octavia II (04-)  
★ Roomster (06-) ★ Superb (08-)  
★ Yeti (09-)

**Suits: VW**

★ Beetle (11-) ★ Caddy (04-)  
★ Eos (06-)  
★ Golf A5 (03-) ★ Golf A6 (08-)  
★ Golf Plus (05-)  
★ Golf Variant (07-)  
★ Jetta (05-) ★ Jetta (11-)  
★ Passat B6 (05-)  
★ Passat B7 (10-)  
★ Passat CC (08-)  
★ Passat US (11-)  
★ Scirocco III (08-) ★ Tiguan (07-)

**Suits: ALDO**

★ FORD MONDEO (11-)  
★ PORSCHE Cayenne (02-)  
★ SEAT Ibiza V 6J (08-)

### OZ ST10 Ready Made Silicone Pad - Ø31mm



**Suits: AUDI**

★ A1 (10-) ★ A3 (10- ★ A4 (07-)  
★ A5 (07-) ★ A5 Convertible (09-)  
★ A6 (10-) ★ Q3 (11- ★ Q5 (08-)

**Suits: BMW**

★ 1 Series F20 (11-)  
★ 3 Series F30 (11-)  
★ 5 Series F10/F11 (10-)  
★ 5 Series GT F07 (09-)  
★ 7 Series F01/F02 (08-)  
★ X3 F25 (07-) ★ X5 E70 (07-)

**Suits: FORD**

★ Edge (11-) ★ Explorer (11-)

**Suits: HOLDEN**

★ Astra J (09-)  
★ VF Commodore (13-)

**Suits: SEAT** ★ Alhambra (10-)

**Suits: VW**

★ Golf A7 (12-)  
★ Golf Convertible (11-)  
★ Passat CC (08-)  
★ Sharan (10-)

### OZ ST11 Ready Made Silicone Pad - Ø27mm



**Suits: ALFA**

★ 147 (00-10) (ARGIC 2037)  
★ 156 Sedan/Estate (97-05)  
★ Brera (06-) - (ARGIC 2040)  
★ GT (04- ★ Spider (06-)

**Suits: CITROEN**

★ C5 (01-08)  
★ C8 (02-) - (ARGIC 2728)

**Suits: FIAT**

★ Grande Punto (05-)  
★ Ulysse (02-11)

**Suits: JAGUAR**

★ S-Type (00-04) ★ X-Type (01-08)  
★ XJ (11/97-03) ★ XK (06-)  
★ XK8 (97-05)

**Suits: LANCIA**

★ Lybra (99-06) ★ Phedra (02-10)  
★ Thesis (02-09) ★ Ypsilon (03-)

**Suits: MERCEDES**

★ A-Class W168 (97-04)  
★ Sprinter I (95-06)  
★ Sprinter I High Roof (95-06)

**Suits: PEUGEOT**

★ 307 (01-07)  
★ 607 (00-10)  
★ 807 (02-)

**Suits: PORSCHE**

★ 996 (08/97-05)  
★ 997 (04-)  
★ Boxster (04-) /Cayman (05-)  
★ Boxster (08/02-05)  
★ Boxster (96-07/02)

**Suits: SEAT**

★ Arosa (97-05)  
★ Ibiza III (00-04/02)  
★ Ibiza IV 6L (05/02-08)  
★ Leon (99-05)  
★ Toledo II (99-04)

**Suits: SKODA**

★ Octavia I (98-04)  
★ Octavia Tour (04-10)  
★ Superb (02-08)

**Suits: TOYOTA**

★ Avensis II (03-08)  
★ Corolla E12 3/5 doors (02-07)  
★ Corolla R1 Verso II (04-)

**Suits: VW**

★ Bora (98-03)  
★ Golf A4 (97-03)  
★ Lupo (97-05)  
★ New Beetle (98-10)  
★ New Beetle Convertible (03-10)  
★ Passat B5 (97-05)  
★ Polo III (6N2) (00-01)  
★ Polo IV (9N/9N2) (01-08)  
★ Polo SD9N (00-04)  
★ T5 (03-)

### OZ ST12 Ready Made Silicone Pad Kit - 49 x 37mm



**Suits: CITROEN**

★ C4 (04- ★ C4 Picasso (06-)  
★ C5 (01-08) ★ C8 (02-)  
★ Jumpy II (07-)  
★ Xantia (1993-01)  
★ Xsara (1997-05)  
★ Xsara Picasso (2000-)

**Suits: FIAT**

★ Bravo (07-) ★ Croma II (05-)  
★ Idea (04-) ★ Scudo (07-)  
★ Stilo 3 doors (01-07)  
★ Stilo 5 doors (01-07)  
★ Ulysse (02-11)

**Suits: FORD**

★ Fiesta VI ★ Focus II (04-10)  
★ Kuga (08-) ★ Mondeo II (01-07)

**Suits: HOLDEN/OPEL**

★ Astra H & Astra GTC (04-09)  
★ Astra H Twin Top (07-)  
★ Corsa C (00-06) ★ Movano (10-)  
★ Omega B (94-)  
★ Signum (02-08)  
★ Vectra C (02-08) ★ Vivaro (01-)

**Suits: PEUGEOT**

★ 206 (98-06) ★ 307 (01-07)  
★ 406 (96-04)  
★ 406 Coupé (97-05)  
★ 407 Coupé (05-)  
★ 407 Sedan/Estate (04-10)  
★ 607 (00-10) ★ 807 (02-)  
★ Expert (06-)

**Suits: RENAULT**

★ Clio II (09/98-05)  
★ Espace IV (02-)  
★ Laguna II Sedan/Estate (01-07)  
★ Master II (97-10) ★ Trafic II (01-)  
★ Vel Satis (02-09)

**Suits: SAAB**

★ 9-3 4 doors (02-)  
★ 9-3 Convertible (03-)  
★ 9-5 (97-10)

**Suits: VOLVO**

★ S40 (04-) ★ S40 Sedan (03-)  
★ S60/V70 (00-07) ★ S80 (98-06)  
★ V50 Wagon (03-)  
★ V70 (00-07) ★ XC 90 (02-)

**Suits: ALDO**

★ ALFA 159 Sedan/Estate (05-)  
★ KIA Carnival (99-06)

### OZ ST13 Ready Made Silicone Pad - 46 x 27mm



**Suits: LEXUS**

★ LS 460 (07-)  
★ LS (08-)

**Suits: TOYOTA**

★ Landcruiser 200 Series (08-)

### OZ ST14 Ready Made Silicone Pad - 41 x 24mm



**Suits: LEXUS**

★ GX (03-09)  
★ IS 250/350 (05/13)  
★ LS 430 (00-06)  
★ LX (98-07)  
★ RX 300/400 (03-09)

**Suits: TOYOTA**

★ Landcruiser 100 Series (98-03)

### OZ ST15 Ready Made Silicone Pad - 45 x 24mm



**Suits: LEXUS**

★ GS 300/450 (05-11)  
★ GX (03-09)  
★ GX (10-)  
★ IS 250/350 (05-13)  
★ LS 430 (00-06)  
★ RX 300/400 (03-09)

**Suits: TOYOTA**

★ PRADO 150 SERIES (09-)

## Rain Sensors...

### OZ ST16 Ready Sensor Pad (Trapezoid Shaped) - 41 x 45mm



**Suits:** CITROEN

- ✱ C4 (10- )
- ✱ DS4 (11- )
- ✱ DS5 (11- )

**Suits:** JAGUAR

- ✱ F-TYPE Convertible (13- )

**Suits:** LAND ROVER

- ✱ Range Rover L405 (12- )
- ✱ Range Rover Sport L494 (13- )

**Suits:** MERCEDES

- ✱ A-Class W176 (12- )
- ✱ B-Class W246 (11- )
- ✱ C-Class W205 (14- )
- ✱ S-Class W222 (13- )

**Suits:** PEUGEOT

- ✱ 2008 (13- )
- ✱ 208 (12- )
- ✱ 508 (10- )

### OZ ST18 Audi Q7 Rain Sensor Pad - 46 x 41mm



**Suits:** AUDI

- ✱ A4 (15- )
- ✱ A5 (16- )
- ✱ A5 Convertible (17- )
- ✱ Q5 (17- ) ✱ Q7 (15- )

**Suits:** PORSCHE

- ✱ Panamera (16- )

NEW

### OZ ST21 Ready Made Rain Sensor Pad - Ø31mm



**Suits:** HYUNDAI

- ✱ Genesis (15- )
- ✱ H350 (15- )
- ✱ Kona (17- )
- ✱ Niro (16- )
- ✱ Rio (17- )

**Suits:** SEAT

- ✱ Alhambra (10- )
- ✱ Arona (17- )
- ✱ Ateca (16- )
- ✱ Ibiza V 6F (17- )
- ✱ Leon III (12- )
- ✱ Toledo IV (12- )

**Suits:** SKODA

- ✱ Fabia III (14- )
- ✱ Superb (15- )

**Suits:** VW

- ✱ Crafter (17- )
- ✱ Golf A7 (12- )
- ✱ Golf Convertible (11- )
- ✱ Golf Sportsvan (13- )
- ✱ Passat B8 (14- )
- ✱ Passat CC (08-16)
- ✱ Polo (09-17)
- ✱ Polo (17- )
- ✱ Sharan (10- )
- ✱ T-Roc (17- )
- ✱ Tiguan (16- )
- ✱ Transporter T6 (16- )

### OZ ST20 Ready Made Rain Sensor Pad - 26 x 26mm



- Suits:** ✱ SUBARU Outback (15- )

NEW

### OZ ST19 Rain Sensor Silicone Pad - Ø44mm



**Suits:** MERCEDES BENZ

- ✱ IRIZAR i8 (15- )
- ✱ Actros (cab width 2.3m) (12- )
- ✱ Actros (cab width 2.5m) (12- )

- Suits:** SCANIA ✱ 6 Series R/S (16- )

- Suits:** VDL ✱ Futura (10- )

## Defroster Repair Kit

Equalizer.

### DRK672 Equalizer Master Defroster Repair Kit



- ✱ Comes with everything you need to easily make dozens of repairs on damaged elements and tabs. ✱ Reattach or replace tabs - sand lightly to remove oxidation from the defroster grid then apply resin and hardener, attach the tab and let it cure, then you can reattach the lead wires. ✱ The solder in this kit is in a paste form so it can be placed on both the tab and grid, easily bonding together.
- ✱ Each kit contains a grid repair solution for those times when the electrical grid is no longer creating a circuit. ✱ The kit includes several types of replacement connectors. ✱ Neatly packaged in a compartmentalised plastic box.