

## Windscreen Rubbers

### BEDFORD

#### OZ-1124 CF 1970-1981

Without inserts for moulds  
GM276, BE951, 818840

#### OZ-1126 TK 1962-1981

Needs GL1 rubber locking strip  
GM274, BE716, 818150

### CHEVROLET

#### OZ-1193 C20 GMC Suburban / Silverado 1972-1993

Without inserts for moulds  
US850

#### OZ-1256 Bel Air 1955-1957

2 Door Hard Top / 2-4 Door Sedan  
With inserts for moulds  
US396 US394 US512 US513 033940  
035120 035130 033960

### DAIHATSU

#### OZ-1087 Delta V10/20/30 1977-1984

Without inserts for moulds  
TT553, TT630, 819790

#### OZ-1053 Delta 1984-2003 Wide Cab

Without inserts for moulds  
DU569, TT1461, 819793

#### OZ-1192 Delta 1984-2003 Narrow Cab

Without inserts for moulds  
81972, TT1460

### DATSUN

#### OZ-1097 1200 B110 1971-1985

Sedan  
Without inserts for moulds  
REAR

#### OZ-1011 1200 B110 1971-1985

Without inserts for moulds  
DN098, DN802, 230850

#### OZ-1101 120Y B120 1973-1979

Sedan  
With inserts for moulds  
REAR

#### OZ-1135 1600 P510 1967-1979

Sedan  
With inserts for moulds  
REAR

#### OZ-1133 1600 P510 1967-1979

With inserts for moulds  
DN103, DN803, 230770

#### OZ-1072 720 1979-1985 Ute

Without inserts for moulds  
REAR

### DODGE

#### OZ-1041 AT D5N / International

AA110 AB110 AA60 1958-1980  
Without inserts for moulds  
IH534, IH796, 818600



LHS

## A-PILLAR MOULDS

RHS

See the Windscreen Moulds section for full details of each mould.

### BMW

3 Series F30 F31 2012-2019 **OZ-606** (L) / **OZ-607** (R)



5 Series E60 E61 2003-2010 **OZ-602** (L) / **OZ-603** (R)



### LANDROVER

Discovery 3 L319 2004-2009 **OZ-626** (L) / **OZ-627** (R)



### FORD

Fiesta 2008-2019 **OZ-610** (L) / **OZ-611** (R)



Mondeo 2007-2009 **OZ-608** (L) / **OZ-609** (R)



### MINI

Cooper R50 R53 2002-2007 **OZ-600** (L) / **OZ-601** (R)



Cooper R56 2007-2014 **OZ-604** (L) / **OZ-605** (R)




### HYUNDAI

iLoad/iMax TQ 2008- **OZ-630** (L) / **OZ-631** (R)



Santa Fe DM 2012-2018 **OZ-632** (L) / **OZ-633** (R)



### LEXUS

IS250/350 2005-2013 **OZ-622** (L) / **OZ-623** (R)



### TOYOTA

RAV 4 ACA20R ACA22R 3DR 2000-2006 **OZ-618** (L) / **OZ-619** (R)



RAV 4 ACA21R 5DR 2000-2006 **OZ-620** (L) / **OZ-621** (R)



## Windscreen Rubbers

### FORD

**OZ-1108 Cargo 1981-1992**

Without inserts for moulds  
FD168, FD1111, 838801

**OZ-1010 Cortina TC-TD 1971-1976**

Use GEMINI Mylar  
FD060, FD744, 231500

**OZ-1009 Courier 1967-1985**

With inserts for moulds  
MA071, MA784, 839330

**OZ-1113 D Series 1965-1981**

Without inserts for moulds  
FD311, FD740, 818800

**OZ-1095 Escort MK1 1969-1975**

Sedan  
With inserts for moulds

**REAR**

**OZ-1092 Escort MK1 1969-1975 /**

**MK2 Panelvan 1969-1982**

With inserts for moulds  
FD062, FD664, 231550

**OZ-1008 Escort MK2 1975-1983**

With inserts for moulds  
FD063, FD924, 231560

**OZ-1007 F100 1957-1960**

With inserts for moulds  
FD030, FD496, 818780

**OZ-1006 F100/250 1973-1997**

Without inserts for moulds  
**REAR**

**OZ-1005 F100/250/350 1968-1981**

Without inserts for moulds  
FD687, FD748, 838790

**OZ-1151 Falcon XA XB ZF ZG**

**Fairlane**

With inserts for moulds  
**REAR**

**OZ-1155 Falcon XA XB XC Coupe**

With inserts for moulds  
**REAR**

**OZ-1160 Falcon XA XB XC Ute**

With inserts for moulds  
**REAR**

**OZ-1179 Falcon XC Sedan / ZH**

**Fairlane**

With inserts for moulds  
**REAR**

**OZ-1132 Falcon XD XF Sedan**

Without inserts for moulds  
**REAR**

**OZ-1167 Falcon XK XL XM XP Coupe**

With inserts for moulds  
FD065, FD1592, 231660

**OZ-1176 Falcon XK XL XM XP**

**Sedan/Wagon**

With inserts for moulds  
FD064, FD1191, 231650

**OZ-1165 Falcon XR XT ZA ZB**

Without inserts for moulds  
**REAR**

**OZ-1136 Falcon XW XY GT Fairmont / ZC ZD Fairlane**

Without inserts for moulds  
**REAR**

**OZ-1168 Falcon XW XY 500 Futura**

With inserts for moulds  
**REAR**

**OZ-1178 Falcon XW XY XR XT Ute**

Without inserts for moulds  
**REAR**

**OZ-1065 Louisville 1975-1997**

Without inserts for moulds  
FD828, FD926, 838320

**OZ-1004 Mustang 1964-1968**

Without inserts for moulds  
FD654, FD2295, 036540

**OZ-1057 Trader 1981-1989 Wide**

**Cab**

Without inserts for moulds  
MA072, MA1254, 839311

**OZ-1058 Trader 1989-2000 Wide**

**Cab**

Without inserts for moulds  
MA073, MA1691, 819313

### HINO

**OZ-1163 Dutro 200 300 2000-2010**

**Standard Cab**

Without inserts for moulds  
TT105, TT1462, 838992

**OZ-1175 Dutro 300 400 500**

**2000-2010 Wide Cab**

Without inserts for moulds  
TT101, TT1463, 818993

**OZ-1088 FD FF 1982-1996**

Without inserts for moulds  
TT171, TT1135, 818981

**OZ-1188 Fleeter Merlin FB FC**

**1985-1996**

Without inserts for moulds  
TT1790

**OZ-1148 KL KB KR KQ LA LB342**

**1970-1985**

Without inserts for moulds  
TT355, TT1914, 818980

**OZ-1186 Ranger 4 5 FB FC**

**1996-2002 Narrow Cab**

Without inserts for moulds  
TT1136

**OZ-1185 Ranger 6 7 8 1991-**

Without inserts for moulds  
TT1949

**OZ-1184 Ranger Pro 5 6 7 8**

**2003- Standard Cab**

Without inserts for moulds  
818998, TT1137

**OZ-1191 Ranger Pro 8 9 10 14**

**1991-2002**

Without inserts for moulds  
TT2130

**OZ-1183 Ranger Pro 9 10 2003-**

**Wide Cab**

Without inserts for moulds  
818997, T1991

### HOLDEN

**OZ-1162 Commodore VB VH**

Use COMMODORE Mylar  
**REAR**

**OZ-1158 Commodore VB VH Exec**

Use COMMODORE Mylar  
GM464, GM763, 232020

**OZ-1091 Commodore VB VK**

Without inserts for moulds  
GM464, GM963, 232020

**OZ-1156 Commodore VC VK SL/E**

**Calais**

With inserts for moulds  
GM464, GM763, 232020

**OZ-1166 Commodore VC VL SL/E**

**Calais**

With inserts for moulds  
**REAR**

**OZ-1105 Commodore VK VL Sedan**

Without inserts for moulds  
**REAR**

**OZ-1142 EH Sedan**

With inserts for moulds  
**REAR**

**OZ-1174 EJ Sedan**

With inserts for moulds  
**REAR**

**OZ-1066 EJ EH**

With inserts for moulds  
GM075, GM1196, 231970

**OZ-1217 FB EK**

With inserts for moulds  
211960, GM2017

**OZ-1220 FB EK Sedan**

With inserts for moulds  
**REAR**

**OZ-1232 FE FC Standard**

Without inserts for moulds  
231950, GM2016

**OZ-1199 FE FC Special**

With inserts for moulds  
231950, GM2016

**OZ-1198 FJ FX Front/Ute**

Without inserts for moulds  
201940, GM575 **REAR**

**OZ-1003 Gemini TX TC TG**

**1975-1984**

Use GEMINI Mylar  
GM084, GM727, 232320

**OZ-1181 HD Sedan**

With inserts for moulds  
**REAR**

**OZ-1128 HD HR**

Without inserts for moulds  
GM076, GM730, 231980

**OZ-1130 HD HR**

With inserts for moulds  
GM076, GM730, 231980

**OZ-1172 HD HG HK HR HT Ute**

Without inserts for moulds  
**REAR**

**OZ-1125 HG HK HT Kingswood**

**(Sqr Cnrs)**

Without inserts for moulds  
GM077, GM731, 231990

**OZ-1147 HG HK HT Monaro**

With inserts for moulds  
GM080, GM734, 232150 FRONT

## Windscreen Rubbers

### HOLDEN cont...

**OZ-1170 HG HK HT Monaro**  
With inserts for moulds

REAR

**OZ-1144 HG HK HT Premier / Brougham**  
With inserts for moulds

REAR

**OZ-1122 HG HK HT Premier (Sqr Cnrs)**  
With inserts for moulds  
GM077, GM731, 231990

**OZ-1140 HG HT Kingswood**  
With inserts for moulds

REAR

**OZ-1127 HG HT Kingswood Sedan (Round Cnrs)**  
With inserts for moulds  
GM078, GM732, 232000

**OZ-1180 HK Kingswood**  
With inserts for moulds

REAR

**OZ-1106 HQ WB Ute**  
Includes rubber locking strip

REAR

**OZ-1182 HR Sedan**  
With inserts for moulds

REAR

**OZ-1035 Jackaroo 1981-1992**  
Without inserts for moulds  
GM154, GM1116, 232120

**OZ-1002 Rodeo KB 1981-1988**  
Without inserts for moulds  
GM047, GM1107, 232120

**OZ-1118 Rodeo TF 1988-2003**  
Without inserts for moulds

REAR

**OZ-1138 Torana LC LJ 1967-1974**

2/4 Door

Use TORANA Mylar

GM082, GM736, 232250 FRONT

**OZ-1141 Torana LC LJ 1967-1974**

2/4 Door

Use TORANA Mylar

REAR

**OZ-1137 Torana LH LX UC 1974-1980 Sedan**

Use TORANA Mylar

REAR

**OZ-1052 Torana LH LX UC 1974-1980 Sedan/Hatch**

Use TORANA Mylar

GM083, GM737, 232260

**OZ-1152 Torana LH LX UC 1974-1980 Hatch**

Use TORANA Mylar

REAR

### INTERNATIONAL

**OZ-1036 Acco A B C D E Line 1973- (3 Wipers)**

Includes rubber locking strip

IH320, IH798, 819030

**OZ-1041 AA110 C1100 D1910**

1958-1980

Without inserts for moulds

IH534, IH796, 818600

**OZ-1063 N1630 N1650 N1750**

1983-1996

Without inserts for moulds

IH460, IH1428, 818491

**OZ-1234 Acco S Line 1986-1998**

Includes rubber locking strip

IH1631, 819093

**OZ-1056 Acco T Line 1980-1997**

Includes rubber locking strip

IH713, IH1008, 839060

### ISUZU

**OZ-1189 FRR FSR FVM FVR FTR FVZ**

1996-2008

Without inserts for moulds

GM2003

**OZ-1120 FSR FSS FTR FVM FVR FVZ**

1986-1996

Without inserts for moulds

GM650, GM1519, 818221

**OZ-1112 SBR JBR JCR JCM**

1975-1986

Without inserts for moulds

GM322, GM876, 818220

### IVECO

**OZ-1045 Stralis Standard Cab 2004-**

**/ Powerstar 1995- / Eurotech 1995-**

Without inserts for moulds

IH202, IH2075, 819075

### JAGUAR

**OZ-1119 XJ6 Series 1 2 1969-1979**

Front

With inserts for moulds

JG205, JG710, 230710

**OZ-1231 XJ6 Series 1 2 1969-1979**

Rear

With inserts for moulds

230710 REAR

### KENWORTH

**OZ-1145 K100G 1995-1998 High**

Roof Wing Return

Includes rubber locking strip

KW006, KW1014, 819114



**OZ-1146 K104 K108 K200 1999-**

Includes rubber locking strip

Adhesive to Rubber

KW714, KW1015, 819125



**OZ-1116 K104 K108 K200 1999-**

Includes rubber locking strip

Adhesive to Rubber

KW715, KW1016, 1017, 819123, 819124



**OZ-1257 T300 T350 T401 T404**

1998- Euro Cab

Includes rubber locking strip

KW1631, 819115



**OZ-1131 T601 T605 T900 T950**

1995- High Roof

Includes rubber locking strip

KW003, KW764, 839112



### LAND ROVER

**OZ-1046 Defender 1984-**

Without inserts for moulds

RV599, RV1469, 819141

**OZ-1051 Range Rover 1970-1993**

Needs GL1 rubber locking strip

RV250, RV711, 214120

### MAZDA

**OZ-1068 Parkway 1972-1981**

Includes rubber locking strip

MA493, MA1036, 819360

**OZ-1057 T3000 1981-1989 Wide**

Cab

Without inserts for moulds

MA072, MA1254, 839311

**OZ-1058 T3000 1989-2000 Wide**

Cab

Without inserts for moulds

MA073, MA1691, 819313

### MERCEDES BENZ

**OZ-1099 114 115 Series 1968-1976**

4 Door Sedan

With inserts for moulds

MB224, MB884

**OZ-1100 114 115 Series 1968-1976**

4 Door Sedan

With inserts for moulds

REAR

**OZ-1048 Actros 1997-**

Without inserts for moulds

MB338, MB2150, 819381

**OZ-1194 G Class 460 461 463**

1979-1992

Without inserts for moulds

MB1416 / MB1415 / MB1416

**OZ-1074 LS 1418 1967-1988 High**

Cab

Without inserts for moulds

MB524, MB891, 819400

**OZ-1107 V Series 1974-1997**

Standard Cab

Without inserts for moulds

MB337, MB902, 819430

### MINI

**OZ-1047 Leyland 850 1000 1100**

1961-1978

Includes rubber locking strip

LY001, LY701, 233600

**OZ-1207 Leyland 850 1000 1100**

1961-1978

Use GL1 rubber locking strip or MINI Mylar

REAR

## Windscreen Rubbers

### mitsubishi

#### OZ-1067 Canter FE200 1978-1985

##### Wide Cab

Without inserts for moulds  
CH767, CH1056, 818650

#### OZ-1109 Canter FE300 FE339

##### 1986-1995 Narrow Cab

Without inserts for moulds  
CH628, CH1655, 818653

#### OZ-1049 Canter FE400 1986-1996

##### Wide Cab

Without inserts for moulds  
CH627, CH1530, 818652

#### OZ-1061 FK415 FM555 1985-1995

Without inserts for moulds  
CH589, CH1368, 838632

#### OZ-1114 FUSO FK102 FM215

##### 1982-1992

Without inserts for moulds  
CH724, CH1055, 818631

#### OZ-1039 L200 D50 MA MB MC MD

##### 1979-1986

Without inserts for moulds  
CH673, CH999, 838660

#### OZ-1018 L300 Express Starwagon

##### 1980-1986

Without inserts for moulds  
CH730, CH1046, 838670

#### OZ-1089 L300 Express Starwagon

##### 1986-2013

Without inserts for moulds  
CH655, CH1527, 818671

#### OZ-1016 Pajero NC NF NG

##### 1983-1991

Without inserts for moulds  
CH340, CH1326, 235180

#### OZ-1069 Rosa B86X 1986-2000

Without inserts for moulds  
CH023, CH1977, 838673

#### OZ-1070 Rosa BE600 BE635 BE649

##### 2000-

Without inserts for moulds  
CH073, CH1979, 838679

### NISSAN

#### OZ-1015 720 1979-1985 Ute

Without inserts for moulds  
DN633, DN1010, 838400

#### OZ-1072 720 1979-1985 Ute

Without inserts for moulds

##### REAR

#### OZ-1075 Atlas Cabstar F23 H41

##### 1994- Narrow Cab

Without inserts for moulds  
DN051, DN2346, 818483

#### OZ-1134 Atlas Cabstar F23W H41W

##### 1991- Wide Cab

Without inserts for moulds  
DN415, DN2137, 818464

#### OZ-1110 Atlas Cabstar F22 H40

##### 1982-1995

Without inserts for moulds  
DN205, DN1410, 818481

#### OZ-1032 Civilian W40 HFO

##### 1982-1999

Without inserts for moulds  
DN562, DN1353, 838399,

#### OZ-1071 Navara D21 D22 1986-

Without inserts for moulds

##### REAR

#### OZ-1153 Patrol G60 G61 1961-1980

Without inserts for moulds

DN118, DN1436, 818420

#### OZ-1195 Patrol GQ MQ Y60

##### 1980-1997

With inserts for moulds  
DN1069

#### OZ-1040RBL Patrol GU Y61

##### 1997-2016 Rear Barn Door L/H

(Small)

##### REAR

#### OZ-1040RBR Patrol GU Y61

##### 1997-2016 Rear Barn Door R/H

(Large)

##### REAR

#### OZ-1014 Patrol GQ MQ Y60

##### 1980-1997

Without inserts for moulds  
DN771, DN1069, 838421

#### OZ-1014RCR Patrol GQ MQ Y60

##### 1980-1997 5 Door Wagon LH/RH

##### Fixed Cargo Window

(interchangeable)

##### SIDE

#### OZ-1014RBL Patrol GQ MQ Y60

##### 1980-1997 Rear Barn Door L/H

(Small)

Without inserts for moulds

##### REAR

#### OZ-1014RBR Patrol GQ MQ Y60

##### 1980-1997 Rear Barn Door R/H

(Large)

Without inserts for moulds

##### REAR

#### OZ-1013 Urvan E23 1980-1986

With inserts for moulds

DN987, DN1094, 838391

#### OZ-1012 Urvan E24 1987-1993

Without inserts for moulds

DN679, DN1552, 818392

#### OZ-1111 Cabstar H40 1982-1995

##### Wide Cab

With inserts for moulds  
DN206, DN1411, 818482

### PORSCHE

#### OZ-1227 911 1965-1989

With inserts for moulds

233830, PS946

### SCANIA

#### OZ-1150 P R T 2 3 Series 1981-1997

Without inserts for moulds

SV270, SV1365, 819531

#### OZ-1044 P R T 4 Series 1997-2004

Without inserts for moulds

SV271, SV1407, 819532

### SUBARU

#### OZ-1019 Brumby Brat 1980-1993

With inserts for moulds

SU711, SV992, 234320

### SUZUKI

#### OZ-1080 Sierra 1981-1991

Without inserts for moulds

SZ114, SZ1129, 234351

### TOYOTA

#### OZ-1084 Celica TA20 TA22

##### 1971-1977

Without inserts for moulds  
TT152, TT826, 234840

#### OZ-1098 Celica TA22 1971-1977

##### Coupe

Without inserts for moulds

##### REAR

#### OZ-1050 Coaster BB20 BB21 BB30

##### HB30 RB20 1981-1993

Without inserts for moulds  
TT404, TT965, 839721

#### OZ-1060 Coaster BB40 BB50 HBZ50

##### XZB50 1993-2017

Without inserts for moulds  
TT025, TT2300, 819722

#### OZ-1082 Corolla KE20 1970-1974

##### 2/4 Door

With inserts for moulds

##### REAR

#### OZ-1081 Corolla KE20 1970-1974

With inserts for moulds

TT147, TT822, 234710

#### OZ-1031 Corolla KE30 1974-1983

Use TORANA Mylar

TT148, TT923, 234730

#### OZ-1079 Corolla KE30 1974-1983

##### Sedan

Use TORANA Mylar

##### REAR

#### OZ-1094 Corolla KE70 1981-1985

##### Sedan

With inserts for moulds

##### REAR

#### OZ-1083 Crown MS50 1967-1971

Without inserts for moulds

TT160, TT828, 234400

#### OZ-1096 Crown MS50 1967-1971

##### Sedan

Without inserts for moulds

##### REAR

#### OZ-1087 Dyna BU20 1977-1984

Without inserts for moulds

TT553, TT630, 819790

#### OZ-1192 Dyna 1984-2003 Narrow

##### Cab

Without inserts for moulds

81972, TT1460

#### OZ-1053 Dyna 1984-2003 Wide Cab

Without inserts for moulds

DU569, TT1461, 819793

## Windscreen Rubbers

### TOYOTA cont ...

**OZ-1038 Hi Ace LH113R RZH103 RZH113 1989-2005**

Without inserts for moulds  
TT791, TT1680, 839782

**OZ-1086 Hi Ace LH113R RZH103 RZH113 1989-2005**

Without inserts for moulds  
**REAR**

**OZ-1030 Hi Ace RH20 RH30**

1977-1983  
Without inserts for moulds  
TT420, TT607, 839780

**OZ-1029 Hi Ace LH50 YH53**

1984-1989  
Without inserts for moulds  
TT330, , TT1151, 839781

**OZ-1076 Hi Lux RN20 RN25 RN27**

1972-1978  
Without inserts for moulds  
TT350, TT837, 819670

**OZ-1028 Hi Lux RN30 LN40**

1978-1983  
Without inserts for moulds  
TT584, TT991, 839671

**OZ-1077 Hi Lux RN30 LN40**

1978-1983  
Without inserts for moulds  
**REAR**

**OZ-1027 Hi Lux RN50 LN60**

1984-1988  
Without inserts for moulds  
TT561, TT1360, 839672

**OZ-1078 Hi Lux RN85 LN85**

1983-1997 (Not Extra Cab)  
Without inserts for moulds  
**REAR**

**OZ-1020 Hi Lux RN85 LN85**

1983-1997  
Without inserts for moulds  
TT727, TT1600, 839674

**OZ-1117 Hi Lux RN85 LN85**

1983-1997 (Extra Cab)  
Without inserts for moulds  
**REAR**

**OZ-1187 LandCruiser 40 Series**

1969-1984 Ute  
Without inserts for moulds  
**REAR**

**OZ-1190 LandCruiser 40 Series**

1969-1984 Ute Rear 1/4  
Without inserts for moulds  
**REAR**

**OZ-1025 LandCruiser 40 Series**

1969-1976 (Wiper Motor at Top)  
Includes rubber locking strip  
TT165, TT834, 819730

**OZ-1026 LandCruiser 40 Series**

1976-1984 (Wiper at Bottom)  
Without inserts for moulds  
TT166, TT853, 839750

**OZ-1024 LandCruiser 50 Series**

1967-1980  
Without inserts for moulds  
TT167, TT832, 839690

**OZ-1023 LandCruiser 60 Series**

1980-1990  
Without inserts for moulds  
TT996, TT1096, 839691

**OZ-1022 LandCruiser 60 Series**

1980-1990  
With inserts for moulds  
TT996, TT1096, 839691

**OZ-1034 LandCruiser 70 Series**

Troopy 1985-2009 /Ute 1999-2009  
Without inserts for moulds  
TT572, TT1492, 839693

**OZ-1021 LandCruiser 70 Series**

1984-1999 Ute  
Without inserts for moulds  
TT573, TT1507, 839692

**OZ-1037 LandCruiser 80 Series**

1990-1997  
Without inserts for moulds  
TT790, TT1799, 839694

**OZ-1033 LandCruiser 80 Series**

1990-1997  
With inserts for moulds  
TT790, TT1799, 839694

**OZ-1085 Liteace KM20 KM21 YN21**

1979-1985  
Without inserts for moulds  
TT728, TT1012, 839655

### UD

**OZ-1062 CP series 14 15 1985-1995**

Without inserts for moulds  
DN, 625, DN1547, 818412

**OZ-1064 CGA CKA Series 45 46**

1983-1992  
Without inserts for moulds  
DN981, DN2202, 818411

**OZ-1073 CK10 CK11 CK20 CK30**

CW40 1971-1991  
Without inserts for moulds  
DN293, DN2070, 818410

**OZ-1063 CMA CMB 86 87**

1983-1996  
Without inserts for moulds  
IH460, IH1428, 818491

**OZ-1129 CWB320 CWB350 CWB450**

CW320 CW350 CW380 1991-  
Without inserts for moulds  
DN626, DN2163, 818413

**OZ-1115 MK LK 1995- Narrow Cab**

Without inserts for moulds  
DN072, DN1960, 818463

**OZ-1134 MK120 MK150 1999-**

Without inserts for moulds  
DN415, DN2137, 818464

**OZ-1121 PK220 PK235 PK240 PK245**

PK250 PK265 CW250 MK250

1995- Wide Cab  
Without inserts for moulds  
DN076, DN2136, 818462

### VALIANT

**OZ-1157 AP5 AP6 VC 1963-1967 Ute**

MADE TO ORDER  
Use COMMODORE Mylar  
**REAR**

**OZ-1139 AP5 AP6 VC 1963-1967**

Use COMMODORE Mylar  
CH029, CH755, 235250 FRONT

**OZ-1169 AP5 AP6 VC 1963-1967**

Sedan  
Use COMMODORE Mylar  
**REAR**

**OZ-1216 R & S Series RVI SVI**

1960-1962 Sedan  
Use COMMODORE Mylar  
235240, CH750

**OZ-1143 VE VF VG 1967-1971 Sedan**

Wagon Ute  
Use COMMODORE Mylar  
CH030, CH757, 253260 FRONT

**OZ-1164 VE VF VG 1967-1971 Sedan**

Use COMMODORE Mylar  
**REAR**

**OZ-1154 VF VG 1969-1971 Coupe**

Use COMMODORE Mylar  
CH031, CH752, 235270

**OZ-1149 VF VG 1969-1971 Coupe**

Without inserts for moulds  
**REAR**

**OZ-1161 VF VG VIP 1967-1971**

Sedan  
Use COMMODORE Mylar  
**REAR**

**OZ-1159 VH CM Charger 1971-1981**

Use VALIANT Mylar  
**REAR**

**OZ-1173 VH CM 1971-1981 Coupe**

MADE TO ORDER  
Use VALIANT Mylar  
**REAR**

**OZ-1171 VH CM 1971-1981 Sedan**

MADE TO ORDER  
Use VALIANT Mylar  
**REAR**

**OZ-1177 VH CM 1971-1981 Ute**

MADE TO ORDER  
Use VALIANT Mylar  
**REAR**

**OZ-1123 VH VJ VK CM CL Charger**

1971-1981  
Use VALIANT Mylar  
CH032, CH760, 235040

### VOLKSWAGEN

**OZ-1102 Beetle 1300 1500 1600**

1967-1977  
Use VOLKSWAGEN Mylar  
VW170, VW761, 215500

**OZ-1103 Beetle 1300 1500 1600**

1967-1977  
Use VOLKSWAGEN Mylar  
**REAR**

**OZ-1042 Kombi 1968-1981**

Without inserts for moulds  
VW176, VW763, 235660

### VOLVO

**OZ-1043 FH Globetrotter 1994-2013**

/ FM Globetrotter 1994-  
Without inserts for moulds  
W015, W2374, 819913