

## Rain Sensors

ALP OZ

### OZ-ST01 Heater Box for Sensor Gel



Designed to improve curing times in cold temperatures. Speeds up curing time from 15 to 20 minutes when using OZ-ST02 refill.

### OZ-ST04 Mould for OZ-ST03 Gel Refill Pack



For Use With OZ-ST03 Gel

POPULAR

### OZ-AUDIRS Audi Rain Sensor Pad



#### Suits: AUDI

- ✦ A1 (10-)
- ✦ A3 + Sportback (04-)
- ✦ A3 Cabrio (08-)
- ✦ A4 Facelift (04-07)
- ✦ A4 (07-)
- ✦ A4 Cabrio
- ✦ A4 Cabrio Facelift (06-)
- ✦ A5 (07-)
- ✦ A5 Cabrio (09-)
- ✦ A6 (04-)
- ✦ A6 (11-)
- ✦ A7 (10-)
- ✦ A8 (07/03-)
- ✦ A8 (10-)
- ✦ TT (06-)
- ✦ TT Cabrio (07-)
- ✦ R8 (07- ✦ Q5 (08-) ✦ Q7 (06-))

#### Suits: FORD

- ✦ Focus (11-)
- ✦ Kuga (12-)
- ✦ Ranger (11-)

#### Suits: SEAT

- ✦ Altea/Toledo (04-)
- ✦ Leon II (05-)
- ✦ Exeo (09-)

#### Suits: ALSO

- ✦ PORCHE Cayenne (10-)
- ✦ TOYOTA Avensis (09-)
- ✦ VW Touareg (10-)

### OZ-ST02 Sensor Gel Refill Pack (Clear)



### OZ-ST03 Sensor Gel Refill Pack (Opaque)



For most VWs 2006 and some other European models

### OZ-ST05 Subaru/Suzuki Sensor Pad - 34 x 26mm



#### Suits:

- ✦ SUBARU Liberty/Outback (09-)
- ✦ SUZUKI Kizashi (10-)

### OZ-ST07 H1 Sensor Pad - Ø44mm



#### Suits: MERCEDES

- ✦ Actros (08-)
- ✦ A Class W169 (04-)
- ✦ B Class W245 (05-)
- ✦ SLK R171 (04-)
- ✦ Sprinter II (06-)
- ✦ Vito II (03-)
- ✦ Colt VI 3 doors (05-)
- ✦ Colt VI 5 doors (04-)

#### Suits: NISSAN

- ✦ 370 Z Cabrio (10-)
- ✦ Cube (09-)
- ✦ Juke (2011-)
- ✦ Micra (11-)
- ✦ Micra K12 (03-)
- ✦ Micra K13 (11-)
- ✦ Murano (08-)
- ✦ Note (06-)
- ✦ Pathfinder II (06-)
- ✦ Patrol Y62 (13-)
- ✦ Dualis(07-)
- ✦ Tiida (04-)
- ✦ X Trail (07-)

#### Suits: RENAULT

- ✦ Clio III (05-)
- ✦ Koleos (08-)
- ✦ Mégane II (02-)

#### Suits: ALSO

- FIAT ✦ Ducato III
- PEUGEOT ✦ Boxer (06-)
- SMART ✦ Roadster (03-)

### OZ-STNOZ Mixer Nozzles For Rain Sensor Gel - Pkt 10



✦ Use with OZ-ST02 and OZ-ST03 for multiple applications

### OZ-ST08 H2 Sensor Pad - Ø44mm



#### Suits: BMW

- ✦ 5 Series F10/F11 (10-)
- ✦ 5 Series GT F07
- ✦ 6 Series F12/F13 (11-)
- ✦ 7 Series F01/F02 (08-)
- ✦ X3 F25 (10-)
- ✦ X5 E70 (07-)
- ✦ X6 E71 (08-)

#### Suits: NISSAN

- ✦ Qashqai (14-)
- ✦ X-Trail (14-)

#### Suits: RENAULT

- ✦ Kangoo III (08-)
- ✦ Koleos (15-)
- ✦ Laguna III (07-)
- ✦ Laguna III Coupé (08-)
- ✦ Mégane III 5 doors (08-)
- ✦ Mégane III CC (10-)
- ✦ Mégane III Coupé (08-)
- ✦ Mégane Scénic III (09-)
- ✦ Wind (10-)

#### Suits:

- ✦ VW Beetle (11-)

#### Suits:

- ✦ SMART ForTwo (07-)

NEW

### OZ-ST24 Renault Koleos Rain Sensor Pad - Ø44mm (oval internal hole)



Suits: ✦ RENAULT Koleos (16-)

## Rain Sensors cont...

### OZ-ST09 Type 7 Sensor Pad - 37 x 50mm



#### Suits: JAGUAR

★ XJ (10-) ★ XK (06-)

#### Suits: LAND ROVER

★ Discovery III (04-)  
★ Evoque (11-)  
★ Freelander II (07-)  
★ Range Rover Sport (05-)

#### Suits: SKODA

★ Fabia II (07-) ★ Octavia II (04-)  
★ Roomster (06-) ★ Superb (08-)  
★ Yeti (09-)

#### Suits: VW

★ Beetle (11-) ★ Caddy (04-)  
★ Eos (06-)  
★ Golf A5 (03-) ★ Golf A6 (08-)  
★ Golf Plus (05-)  
★ Golf Variant (07-)  
★ Jetta (05-) ★ Jetta (11-)  
★ Passat B6 (05-)  
★ Passat B7 (10-)  
★ Passat CC (08-)  
★ Passat US (11-)  
★ Scirocco III (08-) ★ Tiguan (07-)

#### Suits: ALDO

★ FORD MONDEO (11-)  
★ PORSCHE Cayenne (02-)  
★ SEAT Ibiza V 6J (08-)

### OZ-ST10 Ready Made Silicone Pad - Ø31mm



#### Suits: AUDI

★ A1 (10-) ★ A3 (10- ★ A4 (07-)  
★ A5 (07-) ★ A5 Convertible (09-)  
★ A6 (10-) ★ Q3 (11- ★ Q5 (08-)

#### Suits: BMW

★ 1 Series F20 (11-)  
★ 3 Series F30 (11-)  
★ 5 Series F10/F11 (10-)  
★ 5 Series GT F07 (09-)  
★ 7 Series F01/F02 (08-)  
★ X3 F25 (07-) ★ X5 E70 (07-)

#### Suits: FORD

★ Edge (11-) ★ Explorer (11-)

#### Suits: HOLDEN

★ Astra J (09-)  
★ VF Commodore (13-)

#### Suits: SEAT ★ Alhambra (10-)

#### Suits: VW

★ Golf A7 (12-)  
★ Golf Convertible (11-)  
★ Passat CC (08-)  
★ Sharan (10-)

### OZ-ST11 Ready Made Silicone Pad - Ø27mm



#### Suits: ALFA

★ 147 (00-10) (ARGIC 2037)  
★ 156 Sedan/Estate (97-05)  
★ Brera (06-) - (ARGIC 2040)  
★ GT (04- ★ Spider (06-)

#### Suits: CITROEN

★ C5 (01-08)  
★ C8 (02-) - (ARGIC 2728)

#### Suits: FIAT

★ Grande Punto (05-)  
★ Ulysse (02-11)

#### Suits: JAGUAR

★ S-Type (00-04) ★ X-Type (01-08)  
★ XJ (11/97-03) ★ XK (06-)  
★ XK8 (97-05)

#### Suits: LANCIA

★ Lybra (99-06) ★ Phedra (02-10)  
★ Thesis (02-09) ★ Ypsilon (03-)

#### Suits: MERCEDES

★ A-Class W168 (97-04)  
★ Sprinter I (95-06)  
★ Sprinter I High Roof (95-06)

#### Suits: PEUGEOT

★ 307 (01-07)  
★ 607 (00-10)  
★ 807 (02-)

#### Suits: PORSCHE

★ 996 (08/97-05)  
★ 997 (04-)  
★ Boxster (04-) /Cayman (05-)  
★ Boxster (08/02-05)  
★ Boxster (96-07/02)

#### Suits: SEAT

★ Arosa (97-05)  
★ Ibiza III (00-04/02)  
★ Ibiza IV 6L (05/02-08)  
★ Leon (99-05)  
★ Toledo II (99-04)

#### Suits: SKODA

★ Octavia I (98-04)  
★ Octavia Tour (04-10)  
★ Superb (02-08)

#### Suits: TOYOTA

★ Avensis II (03-08)  
★ Corolla E12 3/5 doors (02-07)  
★ Corolla R1 Verso II (04-)

#### Suits: VW

★ Bora (98-03)  
★ Golf A4 (97-03)  
★ Lupo (97-05)  
★ New Beetle (98-10)  
★ New Beetle Convertible (03-10)  
★ Passat B5 (97-05)  
★ Polo III (6N2) (00-01)  
★ Polo IV (9N/9N2) (01-08)  
★ Polo SD9N (00-04)  
★ T5 (03-)

### OZ-ST12 Ready Made Silicone Pad Kit - 49 x 37mm



#### Suits: CITROEN

★ C4 (04- ★ C4 Picasso (06-)  
★ C5 (01-08) ★ C8 (02-)  
★ Jumpy II (07-)  
★ Xantia (1993-01)  
★ Xsara (1997-05)  
★ Xsara Picasso (2000-)

#### Suits: FIAT

★ Bravo (07-) ★ Croma II (05-)  
★ Idea (04-) ★ Scudo (07-)  
★ Stilo 3 doors (01-07)  
★ Stilo 5 doors (01-07)  
★ Ulysse (02-11)

#### Suits: FORD

★ Fiesta VI ★ Focus II (04-10)  
★ Kuga (08-) ★ Mondeo II (01-07)

#### Suits: HOLDEN/OPEL

★ Astra H & Astra GTC (04-09)  
★ Astra H Twin Top (07-)  
★ Corsa C (00-06) ★ Movano (10-)  
★ Omega B (94-)  
★ Signum (02-08)  
★ Vectra C (02-08) ★ Vivaro (01-)

#### Suits: PEUGEOT

★ 206 (98-06) ★ 307 (01-07)  
★ 406 (96-04)  
★ 406 Coupé (97-05)  
★ 407 Coupé (05-)  
★ 407 Sedan/Estate (04-10)  
★ 607 (00-10) ★ 807 (02-)  
★ Expert (06-)

#### Suits: RENAULT

★ Clio II (09/98-05)  
★ Espace IV (02-)  
★ Laguna II Sedan/Estate (01-07)  
★ Master II (97-10) ★ Trafic II (01-)  
★ Vel Satis (02-09)

#### Suits: SAAB

★ 9-3 4 doors (02-)  
★ 9-3 Convertible (03-)  
★ 9-5 (97-10)

#### Suits: VOLVO

★ S40 (04-) ★ S40 Sedan (03-)  
★ S60/V70 (00-07) ★ S80 (98-06)  
★ V50 Wagon (03-)  
★ V70 (00-07) ★ XC 90 (02-)

#### Suits: ALDO

★ ALFA 159 Sedan/Estate (05-)  
★ KIA Carnival (99-06)

### OZ-ST13 Ready Made Silicone Pad - 46 x 27mm



#### Suits: LEXUS

★ LS 460 (07-)  
★ LS (08-)

#### Suits: TOYOTA

★ LandCruiser 200 Series (08-)

### OZ-ST14 Ready Made Silicone Pad - 41 x 24mm



#### Suits: LEXUS

★ GX (03-09)  
★ IS 250/350 (05/13)  
★ LS 430 (00-06)  
★ LX (98-07)  
★ RX 300/400 (03-09)

#### Suits: TOYOTA

★ LandCruiser 100 Series (98-03)

### OZ-ST15 Ready Made Silicone Pad - 45 x 24mm



#### Suits: LEXUS

★ GS 300/450 (05-11)  
★ GX (03-09)  
★ GX (10-)  
★ IS 250/350 (05-13)  
★ LS 430 (00-06)  
★ RX 300/400 (03-09)

#### Suits: TOYOTA

★ PRADO 150 SERIES (09-)

## Rain Sensors cont...

### OZ-ST16 Ready Sensor Pad (Trapezoid Shaped) - 41 x 45mm



**Suits:** CITROEN

- ✦ C4 (10-)
- ✦ DS4 (11-)
- ✦ DS5 (11-)

**Suits:** JAGUAR

- ✦ F-TYPE Convertible (13-)

**Suits:** LAND ROVER

- ✦ Range Rover L405 (12-)
- ✦ Range Rover Sport L494 (13-)

**Suits:** MERCEDES

- ✦ A-Class W176 (12-)
- ✦ B-Class W246 (11-)
- ✦ C-Class W205 (14-)
- ✦ S-Class W222 (13-)

**Suits:** PEUGEOT

- ✦ 2008 (13-)
- ✦ 208 (12-)
- ✦ 508 (10-)

### OZ-ST18 Audi Q7 Camera Pad - 46 x 41mm



**Suits:** AUDI

- ✦ A4 (15-)
- ✦ A5 (16-)
- ✦ A5 Convertible (17-)
- ✦ Q5 (17-)
- ✦ Q7 (15-)

**Suits:** ALSO

- CITROEN ✦ C4 Grand/Picasso (13-)
- MERCEDES ✦ CLS C257 (18-)
- PORSCHE ✦ Panamera (16-)

### OZ-ST19 Rain Sensor Silicone Pad - Ø44mm



**Suits:** MERCEDES BENZ

- ✦ IRIZAR i8 (15-)
- ✦ Actros (cab width 2.3m) (12-)
- ✦ Actros (cab width 2.5m) (12-)

**Suits:** ALSO ✦ VDL Futura (10-)

- ✦ SCANIA 6 Series R/S (16-)

### OZ-ST21 Ready Made Rain Sensor Pad - Ø32mm



**Suits:** HYUNDAI

- ✦ Genesis (15-)
- ✦ H350 (15-)
- ✦ Kona (17-)
- ✦ Niro (16-)
- ✦ Rio (17-)

**Suits:** SEAT

- ✦ Alhambra (10-)
- ✦ Arona (17-)
- ✦ Ateca (16-)
- ✦ Ibiza V 6F (17-)
- ✦ Leon III (12-)
- ✦ Toledo IV (12-)

**Suits:** SKODA

- ✦ Fabia III (14-)
- ✦ Superb (15-)

**Suits:** VW

- ✦ Crafter (17-)
- ✦ Golf A7 (12-)
- ✦ Golf Convertible (11-)
- ✦ Golf Sportsvan (13-)
- ✦ Passat B8 (14-)
- ✦ Passat CC (08-16)
- ✦ Polo (09-17)
- ✦ Polo (17-)
- ✦ Sharan (10-)
- ✦ T-Roc (17-)
- ✦ Tiguan (16-)
- ✦ Transporter T6 (16-)

### OZ-ST20 Ready Made Rain Sensor Pad - 26 x 26mm



- Suits:** ✦ SUBARU Outback (15-)

**NEW**

### OZ-ST23 Audi Q5 Camera Pad - 40 x 42mm



Trapezium shape  
Type 1

**Suits:** AUDI

- ✦ A4 (15-)
- ✦ A5 (16-)
- ✦ A5 Conv (17-)
- ✦ Q5 (17-)
- ✦ Q7 (15-)

**Suits:** ALSO

- ✦ CITROEN C4 Picasso (13-)
- ✦ MERC BENZ CLS C257 (18-)
- ✦ PORSCHE Panamera (16-)

## Defroster Repair Kit

**Equalizer.**

### DRK672 Equalizer Master Defroster Repair Kit



- ✦ Comes with everything you need to easily make dozens of repairs on damaged elements and tabs.
- ✦ Reattach or replace tabs - sand lightly to remove oxidation from the defroster grid then apply resin and hardener, attach the tab and let it cure, then you can reattach the lead wires.
- ✦ The solder in this kit is in a paste form so it can be placed on both the tab and grid, easily bonding together.
- ✦ Each kit contains a grid repair solution for those times when the electrical grid is no longer creating a circuit.
- ✦ The kit includes several types of replacement connectors.
- ✦ Neatly packaged in a compartmentalised plastic box.

## Glass Polishing

### AP4050 Cerium Oxide Polishing Compound - 450g

- ✦ High quality
- ✦ Optical grade



### AP4100 Polishing Buff

- ✦ For removing light scratches and water deposits from glass

